

## Bilstein Shock Installation

**CAUTION: Before installation- With vehicle at proper ride height, measure the distance between the shock mounting points and note. Then collapse and extend the shock fully and measure. The shock should be close to the center of its stroke when installed or at least have 3" of stroke in either direction. IF NOT- THE SHOCK COULD BREAK AND VOID WARRANTY.**

1. Unbolt the original shock and compare to replacement.
2. Install new shock with label and numbering right side up.
3. Tighten bolts to proper torque, do not over tighten bushings.