



### Install Instructions for SS407-16K & SS842-14K

1. Measure length of draglink and compare to replacement
2. Remove cotter pins and loosen nuts on both ends.
3. Pop tapers loose and remove draglink.
4. Re Install with new boots and grease fittings.
5. Tighten nuts to proper torque.
6. Install cotter pins.
7. Grease both ends until grease can be seen at boots.
8. Have an alignment done

NOTE: SS407-16K IS 11" center to center, SS842-14K IS 13.5" center to center.

**Your comments are greatly appreciated.**  
**Please feel free to contact SuperSteer® at 888-898-3281**  
**Or e-mail at [john@supersteerparts.com](mailto:john@supersteerparts.com)**

